

WE EMPOWER THE
THINKERS, DOERS, AND
MAKERS TO BUILD A
MORE VIBRANT WORLD.
IF YOU ARE NEVER
SATISFIED BY WHAT IS,
BUT IMAGINE WHAT
COULD BE, THEN YOU
ARE ONE OF US.

YOU ARE THE
Creative.

Jot Touch Glossary

各部名称

EN

1. Precision Disc

Mimics the capacitance signature of your finger while allowing you to see exactly where you're drawing

2. Pressure Sensitive Tip

3. Button A

Shortcut Button

4. Power Button

Power On / Off and Bluetooth pairing

5. Button B

Shortcut Button

6. Indicator Light

Notifies you of Bluetooth connection, battery level, and when charging

7. Charging Tip

Charging Tip sits on USB charger

8. USB charger

Plugs into any USB port

9. Protective Cap

Twists on to front and back

Replacement Tip
Located behind instruction manual



JP

1. 導電性ディスク

先端に透明ディスクを採用。アイデアをそのまま正確に画面に伝えることができます。

2. 感圧センサー

3. Aボタン

ショートカットボタン

4. 電源ボタン

電源オン/オフ
Bluetoothペアリング

5. Bボタン

ショートカットボタン

6. インジケータースランプ

Bluetooth接続状態、
バッテリー残量、充電状態
を表示します。

7. 充電コネクタ

充電時にUSB充電ドックへ
接続します。

下記はパッケージ同梱品

● USB充電ドック

USBポートへ接続します。

● 保護キャップ

ねじ込み式のキャップで先端ディスク部分を保護します。使用時は外して本体後部へ装着できます。

交換用の導電性ディスクと感圧センサーは取扱説明書の裏にあります。

Getting Connected

接続方法

EN




Bluetooth Pairing

1. On your device, navigate to Settings > General > Bluetooth, then turn on Bluetooth.
2. Without touching the tip of the stylus, press and hold the power button in the grip area.
Touching the disc will incorrectly calibrate Jot Touch to it's zero position. If pressed simply shut off and restart.
3. Continue holding until you see the red / green flashing.
4. Select Jot Touch after it appears in the list of pairable items in your device's settings
5. Once selected, enter the pin "0000" to confirm your pairing with the correct device.
6. Once successfully paired, the indicator light will flash green and the device settings will show that Jot Touch is connected.
7. If unsuccessful, the indicator light will flash red.
8. If this happens, please turn Jot Touch completely off and restart the sequence.
9. To turn your Jot Touch off, press and hold the power button until the indicator light flashes red.



JP

Bluetoothペアリング方法

1. 接続する機器のBluetooth設定からBluetooth機能をオンにしてください。
2. 電源ボタンを長押しして電源を入れます。
※電源ボタンを押したまま手順3へ
※この時先端のディスク部分を触らないでください。
触ってしまった場合は電源をオフにして再度やり直してください。
3. インジケータランプが赤／緑に点滅するまで電源ボタンを押し続けてください。
4. 接続する機器のBluetoothペアリングリストに表示されたらJot Touchを選択してください。
5. パスキーの入力が必要な場合は数字の0を4回「0000」を入力してください。
※接続する機器によっては、パスコードの入力が必要な場合もあります。
6. 接続が完了したらインジケータランプが緑に点滅します。
 1回点滅
7. 接続に失敗している場合は、インジケータランプが赤で点滅します。
 1回点滅
8. 接続に失敗した場合は、Jot Touchの電源をオフにして最初の手順からやり直してください。
9. Jot Touchの電源をオフにするには、インジケータランプが赤く点滅するまで電源ボタンを押し続けてください。
 1回点滅

Charging / Powering up

充電方法 / 電源の入れ方

EN

Charging the Battery

When your Jot Touch needs charging, simply plug your provided adaptor into any standard USB connection, following these instructions.

1. Place the rear of the stylus on the open contacts of the charger; it should attach magnetically, and adhere firmly.
2. Jot Touch's indicator light will turn on, either red or green.
3. Red indicates that the Jot Touch is charging, but that charge value is below 90%.
4. Green indicates that Jot Touch is fully charged.



JP

充電方法

Jot Touchを充電するには、付属のUSB充電ドックをUSBポートに接続し以下の手順をおこなってください。

1. Jot Touch後部の充電コネクタを充電ドックに接続します。マグネット式なのでかんたんに接続できます。
2. Jot Touchのインジケータランプが赤か緑に点灯します。
● / ●
3. 充電が90%以下の場合は赤のランプが点灯します。
●
4. 満充電になると緑に点灯します。
●

残量0～完全充電まで
約2時間

Powering Up

1. Without touching the tip of the stylus, press and hold the power button, until the indicator light flashes green.
2. The green indicator light should flash again once a successful connection has been made with the device.



電源の入れ方

ペアリング済みのデバイスと再度接続する場合。

1. 電源ボタンを押し続けて電源を入れます。
☀ 1回点滅
※この時先端のディスク部分を触らないでください。触ってしまった場合は電源をオフにして再度やり直してください。
2. インジケータランプが緑色に点滅し機器との接続が完了します。
☀ 1回点滅

Resetting / Maintenance

リセット／メンテナンス

EN

Resetting

1. Turn your Jot Touch off.
2. On your device, navigate to Settings > General > Bluetooth, then turn on Bluetooth.
3. Touch the small right arrow next to 'Adonit Touch', then tap 'Forget this Device', and finally touch 'OK'.
4. Turn your Jot Touch on, and repeat the connection process.



JP

リセット

1. Jot Touchの電源をオフにします。
2. 接続する機器のBluetooth設定からBluetooth機能をオンにしてください。
3. 接続する機器のBluetooth設定のリストに表示されたJot Touchを選択し「このデバイスの登録を解除」をタップして登録を解除してください。
4. 再度Jot Touchの電源を入れてBluetoothのペアリングを行ってください。

Battery

The non-replaceable battery in Jot Touch will provide you with up to 12 hours of constant use. When it needs to recharge, the indicator light will flash red every 15 seconds when the battery's capacity reaches 10%.



バッテリー

Jot Touchの内蔵バッテリーは一回の充電で約12時間使用可能です。バッテリーの残量が10%以下になると、インジケータランプが赤く15秒間隔で点滅します。



Cleaning

Jot Touch does not like water, so don't go swimming with it. If you need to clean Jot Touch, please use a slightly damp cloth. Do not attempt to open the stylus, as there are no serviceable parts inside.



クリーニング

Jot Touchは防水ではありませんので水につけて洗うことはできません。汚れてしまった場合は、固く絞った湿った布で拭いてください。スタイラスを分解しないでください。

Removing the disc

To remove the disc, grip it firmly and pull it directly out of the stylus. Do not twist it or pull it at an angle, as damage to the pressure mechanism may result.



ディスクの取り外し方

ディスクを取り外す際は、グリップをしっかりと握って垂直に引いて抜いてください。捻ったり、斜めに引き抜かないでください。感圧センサーの破損などの原因になります。

Jot Ready Apps

Jot Readyアプリ

EN

Jot Ready

Although Jot Touch works with any app, some apps have been calibrated for a smart stylus rather than a finger. These apps have integrated Adonit's Jot Ready SDK (Software Development Kit), so when they are used with Jot Touch it provides the best stylus experience on the market.



Precision

Tablets have been calibrated for fingers. Jot Ready changes that calibration to accommodate a precision stylus.



Pressure Sensitivity

Jot Ready changes the screen's detection to determine how hard you're pressing in any location.



Shortcuts

Jot Ready adds convenient buttons to get you to the tools you need quickly.



JP

Jot Readyとは

Jot Touchはどんなアプリとでも一緒に使うことができますが、Adonit社のJot Ready SDKを使用して開発された対応アプリと組み合わせて使うことにより、もっとも優れたスマートスタイラスとしてのパフォーマンスを体験することができます。

精度

タブレットは指での使用を前提としています。Jot Readyはそれらを精度の高いスタイラスを使用できるタブレットに変更します。

感圧センサー

Jot Readyはスクリーン上でどのくらいの筆圧で描かれているかを検知する機能を追加できます。

ショートカット

Jot Readyで便利なショートカットボタンを追加することができます。

※ショートカットの詳細に関しては各アプリの内容をご確認ください。

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Product contains rechargeable batteries, dispose of properly.

WELCOME TO THE STYLUS REVOLUTION.

**WE WANT TO SEE WHAT
YOU CREATE. SHARE YOUR
JOT CREATIONS. SEE WHAT
OTHERS CREATE.**

WWW.FACEBOOK.COM/ADONITFB